

## PROGRAM YOUR POKER ACE TOURNAMENT WITH RE-BUYS AND ADD-ONS

# 9 or # 10 Custom Tournaments: Program your own structure and store it for next time. (With add-on and re-buys)

To set up your own custom tournament, please follow these directions below.

Turn on the Poker Ace by pressing the “Play Button”



Under the “Select Structure” screen, use the “Down” button and scroll to #9  
Press the Play button to select #9  
Press the Pause button on top of the device to program your custom blinds.

To make your tournament with add-on and re-buys, highlight the selected area buy using the up/down arrows and change the N (no) to Y (yes) using the play button.



Use the Up/Down buttons to highlight the fields you wish to change. Once highlighted, use the Play button or Back button to change the value.



Press the Play button again to start entering custom info. The second option is to select the # of players. Use the arrow Up/Down to choose the number of players in your tournament.



Once you have selected the number of players, press the Play button to enter the amount of starting chips.



Use the Up/Down arrow buttons to select the starting chip stack.  
Once you have selected the starting chip stack, press the Play button.  
Now enter the buy in amount. Use the Up/Down arrows to select the buy in amount, \$1 min \$10,000 max



Once you have selected the buy in amount, press the Play button to access the add-on structure. To edit the Add-on amount, use the arrow Up/Down buttons. (note: the add-on amount is a dollar value which will be added to the prize pool once a player chooses to add-on) Add-on can only be used after a certain level (see below)



Re-buys is your next option to customize. Use the Up/Down arrow buttons to change the re-buy amount. (note: the re-buy amount is a dollar value which will be added to the prize pool once a player chooses to re-buy) see below on how to enter a re-buy.



Now it's time to select the level at which you will allow your players to add-on or re-buy. Use the Up/Down arrows to change the level. (note: at the end of the selected level you will be prompted to select the number of players who have re-bought).



Note: any re-buys and add-ons will directly affect the prize pool.



Press the Pause button to change the payout structure. Then use the Down button to highlight the field you wish to change. For example:

1<sup>st</sup> pays 50%

2<sup>nd</sup> pays 30%

3<sup>rd</sup> pays 20%

Use the Play button or Back button to edit this structure (you can program the device to pay out up to 10 top positions)

Please note the device will automatically adjust the percentages to always total 100%



Once you have adjusted your payout percentages, press the Pause button.

Press the Play button to continue.

Now the device will tell you the prize pool and how much each position will receive.

After starting the tournament, at any point in time you can press the play button to initiate a re-buy. Use the Up arrow to add a re-buy. This will increase the prize pool. After adding the re-buy press the Back button to continue to the tournament screen.



You can adjust your add-ons at the end of the level in which you selected add-on to be available.